

# RODEC® Spare part list for AG0731

No	Part name	Chinese name	Specification	Q'ty	Material	price
1	Bearing set	轴承套		1		
2	Bearing bush	轴承	6017.RS	1		
3	Armature	转子		1		
4	Check ring	轴用挡圈		2		
5	Screw	大头螺钉		2		
6	Bearing	轴承	6100.RS	2		
7	Stop pin	制动销		1		
8	Spring	制动销弹簧		1		
9	Gear box	减速箱		1		
10	Screw	自攻螺钉		4		
11	Check ring	轴用挡圈		1		
12	Bearing	含油轴承		1		
13	Spring washer	波形垫圈		1		
14	Gear	大齿轮		1		
15	Screw	大头螺钉		3		
16	Front cap	前盖		1		
17	Spring washer	弹簧垫圈		4		
18	Screw	螺钉		4		
19	Wheel Guard	防护罩		1		
20	Screw	螺丝		3		
21	End cap	后罩		1		
22	Cord clamp	电缆压板		1		
23	Roller	圆柱销		1		
24	Front handle	辅助手柄		1		
25	Pinion	小齿轮		1		
26	Spring washer	弹簧垫圈		1		
27	Nut	螺母		1		
28	Housing	机壳		1		
29	Stator	定子		1		
30	washer	平垫圈		2		
31	Screw	自攻螺丝		2		

32	Fan guide	挡风圈		1		
33	Brush holder	电刷架		2		
34	Brush)	电刷		1		
35	Screw	螺钉		4		
36	Label	铭牌		1		
37	Capacitor	电容		1		
38	Switch	带断电保护开关		1		
39	Switch drawbar	开关拉杆		1		
40	Switch button	开关推钮		1		
41	)spring	弹簧		1		
42	plug	电缆插头	VDE 2m	1		
43	Cord armor	电缆护套		1		
44	Wood ruff-key	半圆键		1		
45	Spindle	输出轴		1		
46	(Inner Flange	下压板		1		
47	Grinding wheel	砂轮片		1		
48	Outer Flange	上压板		1		
49	Wrench	扳手		1		